
axxiūm

GEL SYSTEM

UV Light Instructional Brochure
ENGLISH

O·P·I

ENGLISH

axxiūm

GEL SYSTEM

FOR PROFESSIONAL USE ONLY. NOT FOR RETAIL SALE OR HOME USE.

For gel application instructions, see brochure enclosed with gel products.

SAVE THESE INSTRUCTIONS

Model # AX 900
Power Source: U.S./CAN 115
Power Consumption: Max. 35 Watts
Weight: 2 lbs.
Dimensions: Length: 10.5"
Width: 7.25"
Height: 6"

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including:

READ ALL INSTRUCTIONS BEFORE USE

KEEP AWAY FROM WATER

CAUTION – ULTRAVIOLET RAYS.

DANGER – TO REDUCE THE RISK OF ELECTROCUTION:

- Do not leave appliance plugged in for an extended period of time when not in use.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not use while bathing.
- Do not place in, or drop into, water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Unplug light before cleaning.

WARNING – TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE, OR INJURY TO PERSONS:

- An appliance should never be left unattended when in use.
- Close supervision is necessary when the appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended use as described in this brochure. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug.
- Keep the cord away from heated surfaces.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair and the like.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used.
- Do not look directly at bulbs when light is on.
- Only use light as intended and as described in the instructions.

TO RETURN AXXIUM UV LIGHT FOR REPAIRS:

- If the UV Light is not working properly due to being dropped or damaged or dropped into water, return the appliance to OPI for examination and repair. To return, carefully pack your AXXIUM UV Light into a box and ship it to **OPI Products Inc., 13034 Saticoy Street, N. Hollywood, CA 91605. Attn: Repair Department.**

SET UP AND GENERAL USE INSTRUCTIONS

- Remove the AXXIUM UV Light from the box and place it on your manicure table, with the open end facing the client.
- Remove any packing materials inside the light.
- Plug the light into a wall outlet.

GEL COMFORT PAD

- Remove the backing from the gel comfort pad and place on top of the AXXIUM UV Light.
- The Gel Comfort Pad may be cleaned by wiping it with an OPI Expert Touch Table Towel or Nail Wipe moistened with N.A.S. 99 Nail Antiseptic Solution.
- Replacement gel pads are available through your Authorized OPI Distributor.

STAINLESS STEEL FINGER PLATFORMS

The AXXIUM UV Light comes with two stainless steel finger platforms to allow proper cleaning and disinfection between clients.

- To clean the platform, wash first with soap and water and then place in disinfection solution for 10 minutes. Rinse and dry before replacing into the AXXIUM UV Light.

AXXIUM GEL CURE TIMES:

Gel Base	1 Minute
Sculpting Gels	2 Minutes
Clear Overlay Gel	2 Minutes
Luminous White Overlay Gel	2 Minutes
No-Cleanse UV Top Sealer	2 Minutes

AXXIUM SOAK-OFF GEL LACQUER CURE TIMES:

Soak-Off Gel Base	1 Minute
Soak-Off Gel Lacquer	2 Minutes
Soak-Off Gel Sealer	3 Minutes

If using a non-OPI UV Light Source, cure times may vary.

THE AXXIUM UV Light features **30-seconds, 1 minute, 2-minutes, 3-minutes, 5-minutes and Continuous ON positions.**

1. Turn the knob to power the appliance. Green LED will come on and built in cooling fan will activate.
2. Position the knob to the desired time region.
3. Push the knob in to turn the bulbs on.
4. If using the Continuous ON position, the knob can be pushed at any time to turn the bulbs on or off.

Turning on the AXXIUM UV Light also activates the built-in cooling fan.

LED BULB LIFE INDICATOR (LED – LIGHT EMITTING DEVICE)

When the AXXIUM UV Light is in use the LED above the knob will be green.

The manufacturer of the UV bulbs strongly recommends replacement after 1000 hours of use due to diminished UV transmission. The LED Bulb Life Indicator will turn red when UV bulbs have reached 1000 hours of use. After replacing the UV bulbs, reset the LED by inserting a pencil into the hole below the LED. The LED will flash 5 times and turn green.

ENGLISH

UV BULB REPLACEMENT INSTRUCTIONS

- Turn the power switch off and disconnect the power cord from the wall outlet.
- Remove housing top for easy access to the UV bulbs.
- Remove UV bulb by holding it firmly and slowly pulling it out of socket.
- To insert a new UV bulb, grasp the bulb firmly and align it with the socket. Push the UV bulb slowly into the socket until you hear it snap into place.

CLEANING THE AXXIUM UV LIGHT

To clean gel residue from the AXXIUM UV Light, use an OPI Expert Touch Nail Wipe or Table Towel moistened with N.A.S. 99 Antiseptic Wipe Solution.

IMPORTANT APPLICATION REMINDERS

- Make sure your work area is clean and dust-free.
- Do not wipe gels with OPI N.A.S. 99 Antiseptic Wipe Solution between application of gels. Wipe only before filing when application is complete and gels are fully cured.
- Use the 15-second timer to freeze gels in place between layers.

CAUTIONS

KEEP ALL PRODUCTS OUT OF THE REACH OF CHILDREN

- Do not use any OPI products on nails that are infected, damaged, extremely thin or weak, have been bitten deep into the nail bed, or are surrounded by sore or inflamed cuticles.
- Discontinue use if sensitization occurs – may cause allergic reactions in certain persons.
- If accidental eye contact occurs, flush with water for 15 minutes and get proper medical attention as soon as possible.
- Keep away from heat and open flame. Exercise due cautions.
- Avoid inhalation or ingestion and prolonged contact with skin.
- If taken internally, get immediate medical attention.
- If AXXIUM gels are spilled on skin or clothing, wipe off with N.A.S. 99 and then wash with mild soap and water.
- Nail adhesives should not come in contact with skin or eyes. If skin bonding occurs, do not pull apart: peel after soaking in OPI Nail, Tip & Glue Remover or OPI 100% Acetone.
- In case of eye contact, flush with ample amounts of water and get immediate medical attention.
- Keep OPI Nail Tips away from direct heat or flame.
- Individuals who are sensitive to light due to fair skin color, or because of certain medications (Tetracyclines, Acutane, Sulfa drugs, etc.), should exercise due caution during exposure to this or any other light source, whether UV or visible. If redness or burning result, discontinue use.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- OPI AXXIUM PRODUCTS ARE DESIGNED TO BE USED AS A SYSTEM. DO NOT INTERMIX WITH OTHER BRANDS AND PRODUCTS.

O·P·I